

INSTRUCTIONS



PARTS

Stroller Carriage



Back Wheel Assembly



Front Wheel Assembly



ASSEMBLY

Step 1: Unhook the side latch to release the stroller carriage.



Step 2: Unfold the stroller carriage. Be sure the two side connectors snap into place.



Page 1

Step 3: Fasten the Velcro straps to the center bar.



Step 4: The rear entrance may be zippered close.



Step 5: Pull forward the awning to zip close the front mesh flap.



Step 6: Slide the back wheel assembly into the back legs until it locks in place.



Each back leg includes a lock tab. When properly inserted, the back wheel assembly fits into these tabs, locking in place. To release the back wheel assembly, press in the tabs and slide out the assembly.



Step 7: Slide the front wheel assembly into the front leg until it locks in place.



To release the front wheel assembly, press the tab underneath the center section to release the lock, and slide out the assembly.



LOCKING THE WHEELS

Each wheel includes a red locking tab. To lock a wheel, press down the tab. To unlock the wheel, lift the tab.



LOCKED



UNLOCKED

FOLDING UP THE STROLLER

The stroller may be folded up when not in use. Detach the Velcro straps from the center bar.

Lift up on the side connectors to release them, allowing the stroller to fold up.



Page 3